


EPSON BRIGHT LINK  
PROJECTOR 1485FI



---

Academic Computer Lab  
[Computerlabs@hccc.edu](mailto:Computerlabs@hccc.edu)

# Interact with your computer



1. The power button

2. Source Search (cycles through connected HDMI sources)

3. Home button, (accesses projector Home screen)

4. User button, auto calibration and press YES.

# Control Box



1. Power button
2. HDMI1/HDMI2 buttons
3. USB-A port
4. USB-B port
5. HDMI1/HDMI2 input ports

# Interactive Pens





- 
1. Pen tip
  2. Battery light

# PC Interactive Mode and Annotation Mode















Pc Interactive Mode: To use the pen and/or finger as a mouse on the projector's image or Whiteboard.

Annotation Mode: To write/draw on the projector's image or Whiteboard with your pen and/or finger.






# The Whiteboard Toolbar




	Displays the Home screen.
	Toggles the video and audio off and on.
	Displays additional tools.  <b>Mail:</b> Shares the projected screen with an email recipient (set up the <b>Mail</b> settings in the <b>Interactive</b> menu first).  <b>Save:</b> Saves the projected screen (set up the <b>Save</b> settings in the <b>Interactive</b> menu first).  <b>Print:</b> Prints the projected screen from a printer on the same network (set up the <b>Print</b> settings in the <b>Interactive</b> menu first).  <b>Timer:</b> Counts the time up or down.  <b>Volume:</b> Adjusts the projector's volume.  <b>Share Projection:</b> Shares the current screen with devices connected using Epson iProjection.  <b>Participant List:</b> Displays the user selection screen so you can project from devices connected to the projector over a network.  <b>Guidance:</b> Displays the help screen for the toolbar functions. Select <b>Close</b> to close the help screen. <b>Clear all drawing contents:</b> Clears all current drawings and images and returns the whiteboard mode to its default status.
	Displays the available pen type, thickness, or shape.  (Yellow/Green/Aqua/Pink/Red/Blue for highlighter): Select the color for the type of pen/shape from the options.
	Switches to the eraser tool to erase content from the whiteboard. Select the size of the eraser.

# Using the Whiteboard Toolbar

You can use both pens and your fingers to interact with the screen and whiteboard toolbar.


1. Press the  Home button on the remote control and select Whiteboard.
2. To move the toolbar to the right, left, top, or bottom of the screen, drag it to the desired location.
3. To add a new page,  select the New page icon above the toolbar.
4. To show or hide the projector control toolbar, select the  icon.



# How to split the projected image with Whiteboard Mode

Select the Whiteboard icon on the left side of the toolbar and you will see the whiteboard display on the screen.

To increase either the whiteboard or the projected image, drag the white part of the center divider to the appropriate side.



# Using the Home Screen



1. Selects the source you want to project

2. Turns off the projector

3. Closes the Home screen

4. Whiteboard

5. Split Screen. Projects images from two or four input sources simultaneously in a grid format

6. Screen Sharing. Shares your projected image with other projectors connected to the same network

7. Connection Guide. In order to connect to the projector you will need to download the Epson iProjection app from the device you are using, such as smartphones or computers.

8. Setting option. You can change the color mode, volume, auto calibration, closed caption and aspect.



# Connection Guide



Please download Epson iProjection before starting.

To connect from your mobile device, go to the home screen and select Connection Guide.

Select Connection with Epson iProjection on your mobile device.

Open the app Epson iProjection on your mobile device and scan the QR Code.

After scanning, you will be connected to the projector and can share and control the projector from your mobile device.




# Easy Interactive Tools

---



## To add Ink annotations in Microsoft Office applications

---



To add Ink annotations in Microsoft Office applications, select the Draw tab.

To annotate your PowerPoint slides in Slideshow mode, press the button on the side of the interactive pen or press the projection surface with your finger for about 3 seconds, and select Pointer Options > Pen from the pop-up menu.

How to use the  
finger as a  
mouse





Troubleshooting

# If the sound is not coming out?

---


Please check the sound  
ICON from your computer  
and unmute it.



# Sound Troubleshooting

If the sound is not coming from the projector, make sure the source of the sound option is the Epson projector.

Click on the sound icon and Select Epson Audio




# Troubleshooting Image

---


If you cannot see the image of your computer screen on the projector or your projector image is blue, try this troubleshooting method.

Press Windows Key + P





- Options for the display will appear, Select Duplicate
- 



# Calibrating for Finger Touch Interactivity

Frequently Used Items	Installation
Image	Fixed Installation Off
Signal I/O	Test Pattern
Installation	Setting Plate Installation Guide
Display	Vertical Installation No
Operation	Projection Front/Upside Down
Management	Auto Screen Adjustment
Network	Geometry Correction Point Correction
Pen/Touch	Digital Zoom
Interactive	Connect ELPCB02 Off
Multi-Projection	Touch Unit
Memory	Remote Receiver Off
ECO	Screen Type 16:9
Initial/All Settings	High Altitude Mode Off
	Reset Installation Settings
	Display
	Pattern Display
	Pattern Type

1. Press the Menu button, select the Installation menu, and press Enter.
2. Select Touch Unit and press Enter.
3. Select Touch YES Calibration and press Enter.
4. Press Enter to select Yes.
5. A green circle appears in the upper left corner of your projected image.
6. Touch and hold the center of the circle with your finger until the circle disappears and another circle appears, then release it.

# Pen Calibration

Calibrate manually if the cursor location and pen position do not match after auto calibration.

1. Press the Menu button, select the Pen/Touch menu, and press Enter.
2. Select Manual Calibration and press Enter.
3. Adjust the image focus, if necessary.
4. Press Enter to select Yes.


A green circle appears in the upper left corner of your projected image.

5. Touch the center of the circle with the tip of the pen.

The circle disappears, and you see another circle below the first one.

6. Once finished, the projector will calibrate.

Frequently Used Items	Pen/Touch
Image	Auto Calibration
Signal I/O	Manual Calibration
Installation	Touch Unit
Display	Installation of Projectors
Operation	Pen Hovering On
Management	PC Interactivity
Network	Reset Pen/Touch Settings
Pen/Touch	Interactive
Interactive	Drawing Function On
Multi-Projection	Display Toolbars Always Show
Memory	Display Drawing Area
ECO	Confirm Clear Screen On
Initial/All Settings	Pen Button Function Eraser
	Display Clock Date & Time ^
	Date YYYY-MM-DD
	Time HH:MM
	Print



# Do you have any questions?

---

Contact Information Technology Services (ITS)

- [Computerlabs@hccc.edu](mailto:Computerlabs@hccc.edu)
- 4358/ 5362/4625